Column 9, line 14, change [channel code] to --select code--.

Column 9, line 53, change [the] (second occurrence) to --then--.

Column 10, line 58, change [display codes] to --select codes--.

Column 11, lines 38-39, change [display code] to --select code--.

Column 11, lines 39-40, change [display code] to --select code--.

Column 12, line 19, change [display code] to --select code--.

Column 12, line 21, change [208] to --210--.

Column 12, line 28, change [display code] to --select code--.

Column 12, lines 29-30, change [display code] to --select code--.

In the Claims

Claim 7, line 21, change "processor signal" to --channel tuning control signal--.

Claim 10, line 1, change "6" to --9--.

Add claims 11-48: